

**COMPONENTS**

**Handle**  
L: 2.70 m

ALFA II C FAWORYT II C VICTORIA II C

**Top track Gemini-Decor**  
L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m

76 mm

**Bottom track Gemini-Decor II**  
L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m

53 mm

**Guiding carriage Focus**


**Angle section**  
Mini 11 mm x 17 mm  
L: 1.70 m, 2.35 m, 3.00 m  
Alfa, Faworyt  
K2-Decor  
L: 1.70 m, 2.35 m, 3.00 m  
Victoria

**Bottom carriage WD18C HI-TEC**

**Bottom carriage WD18V HI-TEC**


Stopper HI-TEC

With ALFA, FAWORYT and VICTORIA sets you may use bottom track **Elegant II with covering strip** along with bottom carriage WD 18V HI-TEC. **Fitting measurements are not affected.**





Dimensions of opening




Handle length = door height


	ALFA II C	VICTORIA II C	FAWORYT II C
	 anti-dust brush (self-adhesive) 6.7 mm x 13 mm textile door stop (inserted) 4.8 mm x 4 mm #16 / #18	 anti-dust brush (self-adhesive) 6.7 mm x 13 mm textile door stop (inserted) 4.8 mm x 4 mm #16 / #18	 anti-dust brush (self-adhesive) 6.7 mm x 13 mm textile door stop (inserted) 4.8 mm x 4 mm #16 / #18
door height - h	$h = H - 42 \text{ mm}$		$h = H - 42 \text{ mm}$
door wing height with soft-close fitted	Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$	Mini SV25/40/60 SV-25/50 $h = H - 42 \text{ mm}$
	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$	Top SV60/80, Central SV25/40 $h = H - 44 \text{ mm}$
board height - hb	$hb = h - 2 \text{ mm}$		$hb = h - 2 \text{ mm}$
door width - w	$w = (W - 3 \text{ mm} + Z) : N$		$w = (W - 3 \text{ mm} + Z) : N$
board width #18 - wb	$wb = w - 22 \text{ mm}$		$wb = w - 19 \text{ mm}$
board width #12 - wb <sub>m</sub>	$wb_m = w - 7 \text{ mm}$		$wb_m = w - 7 \text{ mm}$
angle section length - la	$la = dw - 48.4 \text{ mm}$		$la = w - 33.6 \text{ mm}$
mirror height - hm	$hm = hb - 4 \text{ mm}$		$hm = hb - 4 \text{ mm}$
mirror width - wm	$wm = wb_m - 20 \text{ mm}$		$wm = wb_m - 16 \text{ mm}$

number of doors - N	2	3	4	5	2	3	4	5
total overlap - Z	36 mm	72 mm	108 mm	144 mm	18 mm	36 mm	54 mm	72 mm


visual design – 4 wings		
	$w = (W - 3 + 108) : 4$	$w = (W - 3 + 54) : 4$
	$w = (W : 2 + 33) : 2$	$w = (W : 2 + 15) : 2$



ALFA II C  
VICTORIA II C  
mirror dimensions



FAWORYT II C  
mirror dimensions



**ATTENTION!**  
Handle profile should be 2 mm longer than board height.

**WARNING**  
SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)


**ATTENTION:**  
Board to mirror contact area should be free from dirt and grease before applying double-sided tape.

Broken line indicates recommended positioning of double-sided tape




### VICTORIA II C, ALFA II C

Installation method for handle and guiding carriage with # 18 mm board



- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws  $\text{Ø}3 \times 13$  on the inner door face

Installation method for handle and guiding carriage with # 12 mm board + # 4 mm mirror




If the board or mirror is too loose on the handle profiles, screw the handles to the board using  $\text{Ø}3 \times 10$  screws.

Screw are available from Sevroll-System


### FAWORYT II C

Installation method for handle and guiding carriage with # 18 mm board



- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws  $\text{Ø}3 \times 13$  on the inner door face

Installation method for handle and guiding carriage with # 12 mm board + # 4 mm mirror




If the board or mirror is too loose on the handle profiles, screw the handles to the board using  $\text{Ø}3 \times 10$  screws.

Screw are available from Sevroll-System


### VICTORIA II C

Installation method for angle section K2-Decor





### ALFA II C

Installation method for angle section MINI 11x17 mm




### FAWORYT II C

Installation method for angle section MINI 11x17 mm



### ATTENTION!

Angle section must be fastened to board with minimum 3 screws  $\text{Ø}3 \times 25$ .



### ATTENTION!

Angle section must be fastened to board with minimum 3 screws  $\text{Ø}3 \times 25$ .